



How to reset the NANO computer

Short Circuit
using:
metal tweezers

After having changed the battery (following
*Dive Advisor -powerpoint- instructions up to
reset point*) Reset the NANO Computer.



Soldered
terminals
to reset



When reset has been done
properly; the display shows "Jan
1st, 0 o'clock 00 minutes".
(1- 1 0:00)

SEE POWERPOINT FILE FOR DIVE ADVISOR - ONLY RESET IS DIFFERENT FOR NANO